

# EVO Safety Guidelines for use of PMD Chargers

PMD's (Personal Mobility Devices) Electric Scooters, Skateboards, Hoverboards, Quads, Dirt Bikes, Trikes and Mobility Scooters.

Most PMD Electric Chargers, when in use, will generate a certain amount of heat and be warm to touch, this is normal, however, **if your charger is hot to touch, switch off and seek assistance.**

## Charger Safety Guidelines:

- Your Battery Charger should, **only be placed on a Dry and Non-Flammable Surface**, concrete, tiles, etc. **Do not place on Carpet, Timber Floor, or any other potentially flammable surface.**
- **Your Battery Charger should, never** be covered by any fabric, e.g. towels, clothing or blankets.
- **Your Battery Charger should, never** be used in direct sunlight or near any Heat source, e.g. Room or Space Heater.
- **Your Battery Charger should, not be** located near any form of moisture, including Ice or Water, or wet areas such as bathrooms or laundries.
- **Your Battery Charger should, be not** used outside in weather exposed areas.

**Only use Chargers in cool well-ventilated areas.**

**Keep your Charger out of reach of Children and Animals**

## Charger Operation:

Prior to charging your PMD:

- Ensure your PMD is switched off.
- Ensure the power source/power point to be used is switched off.
- Plug charger into power source/power point.
- Plug charge plug into PMD Charger Port, **ensure the Pins and Keyway are aligned.**
- Turn on the charger at the power source/power point.
- **A Red light** will generally indicate that the charger is charging.
- Please note; when your PMD is fully charged, **a Green Light will appear.**
- When removing the charger or power plugs, only use the respective plugs **do not pull on the cable/cord.**

**Please ensure that no Children or Animals are exposed to or in the vicinity of your PMD while charging.**

## Charger Storage

- Ideally return your charger to the box that it arrived in or a secure container e.g. Plastic Storage container.
- Store the Charger in a secure relatively Cool/Dry Place.

## Our Recommendations

- Store your Charger Securely when not in use.
- **Keep your PMD in your garage or Secure, Dry outdoor location, e.g. Weather Proof Garden Shed**
- **Switch Off your PMD when fully charged and remove charger** from the Power Source and Charger Port on your PMD.
- **Do not charge your PMD overnight** if you need to have your PMD inside.
- **Do not charge your PMD in your Bedroom.**
- **Do not modify your charger in any way to improve performance or application unless you are qualified to do so.**
- **If your Charger is damaged and simply not working, replace it...**
- **... If in doubt 'Throw it out'**

If you think that charger is not working, consult a qualified technician or contact your place of purchase.

**At all times keep your Charger out of reach of Children and Animals**